

Best.-Nr.
Order-Nr.
14.129


Reparaturatz UL100 und UL250

Repair kit UL100 and UL250

Bestehend aus / consisting of:



- V : je 1x Pos.17
- X : je 1x Pos.16, Pos.11, Pos.20, Pos.28
- Y : je 1x Pos.12, Pos.13, Pos.15
- Z : je 1x Pos.6, Pos.7, Pos.8, Pos.9,
Pos.10, Pos.11.1

- V : O-Ring Ausgangsstück Unloader
O-Ring outlet part for Unloader
- X : Reparaturatz Steuerkolben
Repair kit regulation piston
- Y : Reparaturatz Rückschlagventil
Repair kit non return valve
- Z : Reparaturatz Eingangsseite
Repair kit inlet



Montage Pos.16



assembly Pos. 16



Druck
Pressure

Montage Pos.20

assembly Pos. 20



Druck
Pressure

kränzle®

Original Ersatzteil - original spare part